

# BENNETTE

PAINT MFG. CO., INC.  
PRODUCT DATA

## INTERIOR LATEX GLOSS LEVEL 3 32-52 MPI #52

**DESCRIPTION:** A quality interior finish that combines the attractive qualities of an eggshell sheen with the durability of an enamel. It flows evenly and dries fast to a uniform, low-luster finish, the choice of many architects and designers. This product is attractive on both walls and trim.

**SUGGESTED USES:** Interior walls, doors, windows and trim in: Homes, offices, classrooms, hospitals, factories, interior drywall, plaster, CMU, and cement block. Especially suited for kitchens and bathrooms. Ideal for new construction.

**COLORS:** White tint base provides a wide range of pastel colors. Custom colors are readily available.

**FINISH:** Eggshell

**GLOSS:** 10-15°/60°

**VEHICLE TYPE:** Vinyl Acrylic Copolymer

**RECOMMENDED COVERAGE RATES:**

Approximately 400 sq. ft. per gallon @:  
4.0 mils wet film thickness  
1.0 mils dry film thickness

**DRY TIME (@ 77°F and 50% rel. humidity):**

To Touch: 30 minutes  
To Recoat: 8 hours

**MIN/MAX TEMP @ APPLICATION:**

50°F min / 95°F max

**WEIGHT PER GALLON:** 10.5 lbs.

**VISCOSITY:** 95 KU (±2 KU)

**SOLIDS CONTENT:**

By Weight: 45% (±1)  
By Volume: 26% (±1)

**FLASH POINT:** Water-based, Combustible

**RECOMMENDED APPLICATION EQUIPMENT:**

Brush - Quality synthetic brush, such as Purdy Nylox-Swan or Wooster Ultra Pro.  
Roll - Synthetic such as Kodawool or Pro Doo-Z, 1/4" to 3/8" nap  
Spray - Graco or Titan Airless - tip size .015 - .017

**THINNING INSTRUCTIONS:** Thinning is not normally required. If necessary, thin with water, no more than 1/2 pint per gallon.

**CLEAN UP:** Clean brushes, rollers, and spray equipment immediately after use with warm, soapy water.

**SURFACE PREPARATION:** Surface must be free of dirt, chalk, wax or other foreign substances. Glossy surfaces should be sanded and/or scrubbed with a de-glossing solution. Remove mildew with a solution that kills mildew spores. Check adhesion to suspected alkyd or oil paints in an area prior to applying latex coatings. If an adhesion problem is present, use the proper primer as an intermediate coat. New or unpainted surfaces should be primed in accordance with the "Recommended Bennette Primers" section of this sheet.

**RECOMMENDED BENNETTE PRIMERS:**

<i>Block, CMU</i>	Int/Ext Latex Blockfiller	32-4
<i>Concrete</i>	Interior Latex Primer Sealer	32-50
<i>Drywall</i>	Interior Latex Primer Sealer	32-50
<i>Ferrous Metal</i>	Rust Inhibitive Primer (W. B.)	32-107
	Galvanized Primer (W. B.)	32-134
	Anti-Corrosive Metal Primer	32-79
<i>Galvanized</i>	Surface Tolerant Metal Primer	32-23
	Rust Inhibitive Primer (W. B.)	32-107
	Galvanized Primer (W. B.)	32-134
<i>Plaster</i>	Interior Enamel Undercoat	32-46
<i>Wood</i>	Interior Latex Primer Sealer	32-50

*Other primers may be acceptable. Contact Bennette Paint Mfg. Co., Inc. for more information.*

This product was formulated with no mercury compounds, asbestos, silica sand, lead chromate, or insecticide and not more than 0.06 percent lead.

012203



All technical advice, recommendations and services are rendered by the Seller gratis. They are based on technical data that the Seller believes to be reliable, and are intended for use by persons having skill and know-how at their own discretion and risk. Seller assumes no responsibility for results obtained or damages incurred from their use by Buyer in whole or in part. Such recommendations, technical advice or services are not to be taken as a license to operate under or intended to suggest infringement of any existing patent.